PRODUCT USE, CARE AND SERVICE WARRANTY INSTRUCTIONS

celsius

Tower Fan
CELTFSIL



READ AND SAVE THESE INSTRUCTIONS

BEFORE FIRST USE

Read and follow all the instructions in this "Use And Care" even if you feel you are familiar with the product, and find a place to keep it handy for future reference.
Your attention is drawn particularly to the sections concerning "IMPORTANT SAFEGUARDS", "FOR YOUR SAFETY", and the "WARRANTY" and "SERVICE" statements.
For your convenience record the complete model number (located on the product identification plate) and the date you received the product, together with your purchase receipt and attach to the warranty and service information and retain until warranty service is required.
NOTE: The rating of this product (as marked on the product identification plate) is based on specific loading tests. Normal use or the use of other recommended attachments may draw significantly less power.

IMPORTANT SAFEGUARDS

When using any electrically powered product, basic safety precautions should always be followed, including the following:

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT.

WARNING - to reduce the risk of fire, electrical shock or injury to persons or property:

- Always operate the product from a power source of the same voltage, frequency and rating as indicated on the product identification plate.

- To reduce the risk of electric shock, do not use this fan with any solid state speed control device.

- Close supervision is necessary when any product is used by or near children or invalids. Do not allow children to use it as a toy.

- Do not operate any product with a damaged cord or plug, after the product malfunctions, is dropped or appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.

- To reduce the risk of electric shock, do not immerse or expose the product or flexible cord to rain, moisture or any liquid. DO NOT use Fan in or near a window.

- This product should not be used in the immediate vicinity of water, such as bathtub, washbowls, swimming pool etc. where the likelihood of immersion or splashing could occur.

- Never install the unit where it could be subject to:
  * Heat sources such as radiators, heat registers, stoves or other products that produce heat.
  * Direct sunlight
  * Excessive dust
  * Mechanical vibration or shock
  * Lack of ventilation, such as bookcase or cabinet
  * Uneven surface.

- Switch off and unplug from outlet when not in use, before assembling or disassembling parts and before cleaning. Fully assemble the fan before switching on.

- WARNING: DO NOT RELY ON THE ON-OFF SWITCH AS THE SOLE MEANS OF DISCONNECTING POWER WHEN INSTALLING OR SERVICING THE FAN. ALWAYS UNPLUG THE POWER CORD AFTER SWITCHING OFF THE UNIT. REMOVE BY GRASPING THE PLUG - DO NOT PULL ON THE CORD.

- Avoid contacting moving parts. Do not insert any object or fingers through the grill when the fan is operating. Do not block or tamper with the Fan in any manner while it is in operation.

- Do not cover the grill, or operate in close proximity to curtains, etc.

- Always disconnect the fan when moving it from one location to another.

- Always place the Fan on a stable, flat, level surface when operating, to avoid the Fan from overturning. Do not run the power cord under carpet. Do not cover power cord with throw rugs or runners. Route the power cord away from walking paths so that nobody can trip over it. The cable should be kept away from heat, sharp edges and oil.

- Do not use with an extension cord.

- Do not use the Fan without the support bases fitted to the unit.

- The use of attachments or accessories not recommended or sold by the product distributor may cause personal or property hazards or injuries.

- This product is intended for normal domestic/household use only.

READ AND SAVE THESE INSTRUCTIONS

ASSEMBLING YOUR FAN

1. For ease of assembly, lay the Fan down so that the front grill and control panel are facing up.
2. Assemble the Bases by interlocking the guides on Support Base A with Support Base B. Thread the Power Supply Cord through the large hole in the centre of the Support Base Assembly. (Figure1)



Figure 1

3. Secure screws into the four holes in the bottom of the base. (Figure 2)



Figure 2

4. Align the Support Base Assembly with the Column Support Assembly, **noting that the cord channel on the bottom of the support base should be towards the back of the Fan**.
   Note: Ensure that the power cord is routed away from the oscillating mechanism at the base of the fan so that the cord is not damaged or does not prevent the fan from oscillating

5. Assemble the Support Base Assembly to the Column Support Assembly with 4 Screws. Gently pull any excess slack of the Power Supply Cord and place it in the Wire Locating Trough. (Figure 3)



Figure 3

OPERATING THE FAN

This Fan can be operated by the manual controls located on top of the unit (Figure 4).



Figure 4

1. Set the fan base on a dry, level surface.

2. Plug the Power Supply Cord into a **230-240V,** 50 Hz outlet.
   Turn the Fan on by turning the Timer Knob to position "1" and pressing one of the three Speed Buttons marked (1) low, (2) medium, or (3) high. To turn the fan off press the button marked (0).

3. The SPEED is adjusted by pressing one of the three buttons for your desired level of cooling comfort.

4. The OSCILLATION button is located on the top of the fan control panel. To start oscillation, push button down. To stop oscillation, push the button again.As well as oscillating from side to side, this Fan is equipped with a 5-position oscillation mechanism. By holding the head of the unit and gently turned from side to side, locate the most desired direction.

3. The TIMER function allows the unit to be set to operate for a maximum length of time of 120 minutes. By turning the knob to set desired time, the fan will automatically stop when the time concludes. When not using the timer, set the timer knob to position "1".
   Note: If the knob is set at "0" position, the fan will not operate even if you press one of the speed buttons

CLEANING/MAINTENANCE INSTRUCTIONS

Follow these instructions to correctly and safely care for your Tower Fan. Please remember:

1. Switch off and unplug from the power supply before assembling or disassembling and cleaning.
2. Do not allow water to drip on or into the fan motor housing.
3. We also recommend the periodic cleaning of this fan by lightly running a vacuum cleaner nozzle over the fan grill to remove any dust or dirt that may have accumulated inside or on the unit.

Fan Head and Base Cleaning

Using a soft, moist cloth, with or without a mild soap solution, carefully clean the fan housing. Please use caution around the grills. Do not allow the motor or other electrical components to be exposed to water.

Caution: Do not use harsh detergents, chemical cleaners or solvents as they may damage the surface finish of the plastic components.

FAN STORAGE

Your fan can be stored in the off-season either partially disassembled or assembled. It is important to keep it in a safe, dry location.

• If stored disassembled, we recommend using the original (or appropriately sized) box.
• If stored assembled or partially assembled, remember to protect the fan head from dust.

SERVICE OR REPAIR

- For service or repair under warranty, the fan should be returned to the place of purchase or forwarded to the address noted in the guarantee card.
- Do not operate any product with a damaged cord or plug. If the supply cord is damaged, it must be replaced by a special cord assembly available from the manufacturer or service agent. Return the complete product to the place of purchase for inspection, repair or replacement.

TECHNICAL SPECIFICATIONS

MODEL:	CELTFSIL
UNIT WEIGHT:	4.5 Kg
UNIT DIMENSIONS (L x D x H) :	793x180x175 mm
SWIVEL ANGLE:	80°
TIMER:	0 to 120 minutes
POWER CONSUMPTION:	60 W
INPUT VOLTAGE:	230/240V-50Hz
AIR DELIVERY SPEED 3:	550 M3/H

G.A.F. Control (Sales) Pty. Ltd.,
18-28 Taras Ave
Altona North, Victoria, Australia, 3025
Tel no: 1300 659 489

READ AND SAVE THESE INSTRUCTIONS